

Release note

Product: PTC310/PTC310H/PTC310U/PTC330/PTC330U

PTC310N/PTC310HN/PTC310UN/PTC330N

| FW version | V.47 |
|--------------|---|
| Release date | 20221110 |
| New features | 1. none |
| Improvements | 1. Bug fix: TR311HN NDI functionality will be blocked when upgrading to V45 firmware. |
| | 2. Correction Japanese language of OSD menu. |
| | カメラ カメラ選択 1 English |
| | 詳細設定 ステータスOSD オン 繁中 |
| | ビデオ出力 日本語 |
| | ネットワーク |
| | システム カメラ ID - AVer_NO_Camera |
| | タリー 有効にする インフォメーション > |
| | 初期化オフ |
| | |
| Known Issues | 1. Web page compatibility issue with the Apple MAC Safari browser. Please use the Chrome |
| | browser on Apple devices in the meantime. |
| | 2. USB port does not yet support Hot plugging. |
| | 3. When the video mode is set to IP streaming only or NDI only; then when the USB port is |
| | connected to a PC, users will still see the device name on the PC side but there's no USB |
| | video (UVC) output. |
| | 4. HTTPS/port 443 does not work despite HTTPS is enabled at web UI. |



| FW | V0.0.0000.45 | | | | |
|---------|--|---------------------------|------------------------------|---------|---|
| version | | | | | |
| Release | 2022/8/03 | | | | |
| date | | | | | |
| New | 1. Add ability to activate ND | I License key code on web | opage. | | |
| feature | AVer • Live View | NDI Activate Function | | | |
| | Camera Settings | Local Device Name | Device Channel (Camera ID) | | |
| | Video & Audio | | AVer_NDI_Camera | | |
| | 据 Network | Receive Group | | | |
| | Tracking Settings | Public | | | |
| | NDI VDI | Reliable UDP | | | |
| | -vv- System | Discovery Server | Discovery Server Address | | |
| | Tracking Control Tracking On Off | | 192.168.1.10 | | |
| | Mode O Presenter | Multicast Server | Multicast Server Mask | | |
| | Zone Hybrid | | 255.255.255.0 | | |
| | Click Track | Multicast Server Address | Multicast TTL | | |
| | | 239.255.0.0 | 10 | Confirm | с |
| | | | | | |
| | P.S.Please visit NewTek wo https://www.newtek.com/n | | key before activate the NDI. | | |







F., No.157, Da-An Rd., Tucheng Dist,. New Taipei City 23673, Taiwan | Tel: +886-2-2269-8535 | Fax: +886-2-2269-8537 | www.aver.com



Product: PTC310/PTC310H/PTC310U/PTC330/PTC330U

PTC310N/PTC310HN/PTC310UN/PTC330N

| FW | V0.0.0000.43 |
|---------|--|
| version | |
| Release | 2022/5/19 |
| date | |
| New | 3. Add ability to turn off" USB Audio", there's some device only allow to support video and |
| feature | need to close the USB audio to improvement compatibility issue, e.g. Barco Clickshare |
| | CX-50. Webpegg: Video & Audio > USB Audio Op/Off |
| | Webpage: Video & Audio > USB Audio On/Off USB Audio |
| | Off On |
| | 4. Add ability to support LLDP protocol. |
| | 5. Add ability of AF Mode switch: Continuous AF/ AF Trigger after PTZ Setting "AF Trigger after PTZ" will reduce the focusing process picture when presenter is walking around the podium Webpage: Live View > Camera Control > AF Mode |
| | Camera Control Preset Pan Speed 9 < |
| | AF Trigger after PTZ Continuous AF AF Trigger after PTZ ✓ |
| | |



| | 6. Add VISCA | /CGI commands for | USB /UVC status inquire. | | | | | |
|-------------|---|---------------------------|-----------------------------------|--------------------------------|-----|--|--|--|
| | VISA Inquiry Command | Command Packet | Reply Command Packet | Comments | | | | |
| | USB Status | 8x 09 36 69 05 FF | y0 50 00 FF | USB cable plug out | | | | |
| | | | y0 50 01 FF | USB cable plug in | | | | |
| | UVC Status | 8x 09 36 69 06 FF | y0 50 00 FF | UVC stream off | | | | |
| | | | y0 50 01 FF | UVC stream on | | | | |
| | | 1 | | | 1 | | | |
| | CGI | URL | Command | Parameter Name | | | | |
| | item name | | | | | | | |
| | USB status GET(Basic Authentication) /cgi-bin?Get=usb_status_inquire,3 | | | | | | | |
| | - Reply "usb_status_inquire,3=X\r\n" X: 0(plug out), 1(plug in) | | | | | | | |
| | UVC status | GET(Basic Authentication) | /cgi-bin?Get=uvc_status_inquire,3 | | | | | |
| | | - Reply | "uvc_status_inquire,3=X\r\n" | X: 0(stream off), 1(stream on) | | | | |
| Improvement | 3. Bug fixed: RTMP audio issue when streaming to Vimeo | | | | | | | |
| | Ū. | One push AWB of pre | 0 0 | | | | | |
| - | 5. Bug fixed: When the button function is clicked, there will be feedback prompting the user. | | | | | | | |
| Known | 5. Web GUI has known compatibility issue with the Apple MAC Safari browser. Please use | | | | | | | |
| Issues | the Chrome browser on Apple devices for the meantime. | | | | | | | |
| | - | es not yet support He | 1 00 0 | | | | | |
| | | | set to IP streaming only or | • | | | | |
| | - | | still see the device name or | the PC, but will not have | any | | | |
| | USB streaming | output. | | | | | | |





Product: PTC310/PTC310H/PTC310U/PTC330/PTC330U

PTC310N/PTC310HN/PTC310UN/PTC330N

| FW | V0 | .0.0000.42 | | | | | | |
|-------------|--|--|--|--|--|--|--|--|
| version | | | | | | | | |
| Release | 202 | 22/4/06 | | | | | | |
| date | | | | | | | | |
| New | 2. | "Preset Accuracy" f | function is to i | mprove for special | movement in hybrid Tracking mode. | | | |
| feature | | movement will affect area. | ct a little bit o g "Preset Acc Preset Save Preset 0 1 Video Freeze while v Video Freeze while Preset Accuracy | f hybrid Tracking m uracy" when use Hy Save | on of backlash issues, but the node when presenter go into preset ybrid Tracking mode. | | | |
| | Add ability to move the preset when presenter touch the boundary of preset in Zone Tracking mode. Add customized VISCA commands for Auto Zoom/ Auto Tilt. | | | | | | | |
| | | Tracking mode. | - | - | | | | |
| | 4. | Tracking mode. | - | - | | | | |
| | 4. | Tracking mode. Add customized VIS | SCA comman | ds for Auto Zoom/ A | Auto Tilt. | | | |
| | 4. | Tracking mode. Add customized VI | SCA comman | ds for Auto Zoom/ A | Auto Tilt. | | | |
| | 4. | Tracking mode. Add customized VIS Command Set Auto zoom | SCA comman Command On | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF | Auto Tilt. | | | |
| | 4. | Tracking mode. Add customized VIS | SCA comman Command On Off | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF | Auto Tilt. | | | |
| | 4. | Tracking mode. Add customized VIS Command Set Auto zoom | SCA command Command On Off On | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF | Auto Tilt. | | | |
| Improvement | 4. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset | SCA command Command On Off On Off Set | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF | Auto Tilt. Comments | | | |
| Improvement | 4. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam | SCA command On Off Off Off Set ne and passwo | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset | | | |
| Improvement | 4. 6. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Bootup p | SCA command Command On Off On Off Set ne and passwo process impro | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page ve when camera set | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. | | | |
| Improvement | 4. 6. 7. 8. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Bootup p Bug fixed: Disable A | SCA command Command On Off On Off Set ne and passwo process impro Auto Tracking | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page we when camera sett g at bootup if power | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. ting on mirror or flip. | | | |
| | 4. 6. 7. 8. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Bootup p Bug fixed: Disable A | SCA command Command On Off On Off Set ne and passwo process impro Auto Tracking n compatibilit | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page ve when camera sett g at bootup if power | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. ting on mirror or flip. on & off to preset is active. ple MAC Safari browser. Please use | | | |
| Known | 4. 6. 7. 8. 7. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Bootup p Bug fixed: Disable A Web GUI has known | SCA command On Off Off Set De and passwo process impro Auto Tracking n compatibilit r on Apple dev | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page ve when camera sett g at bootup if power by issue with the App vices for the meanting | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. ting on mirror or flip. on & off to preset is active. ple MAC Safari browser. Please use | | | |
| Known | 4. 6. 7. 8. 7. 8. | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Usernam Bug fixed: Disable A Web GUI has known the Chrome browser USB port does not y | SCA command On Off Off Set De and passwo process impro Auto Tracking n compatibilit r on Apple dev yet support Ho | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page ve when camera sett g at bootup if power cy issue with the App vices for the meanting of plugging. | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. ting on mirror or flip. on & off to preset is active. ple MAC Safari browser. Please use | | | |
| Known | 4. 4. 6. 7. 8. 7. 8. W1 | Tracking mode. Add customized VIS Command Set Auto zoom Auto Tilt Auto Zoom/Tilt preset Bug fixed: Usernam Bug fixed: Usernam Bug fixed: Disable A Web GUI has known the Chrome browset USB port does not y nen the video mode v | SCA command Command On Off On Off Set ne and passwo process impro Auto Tracking n compatibilit r on Apple dev yet support Ho via the web is | ds for Auto Zoom/ A Command Packet 8x 01 04 A0 02 FF 8x 01 04 A0 03 FF 8x 01 04 A7 02 FF 8x 01 04 A7 02 FF 8x 01 04 A7 03 FF 8x 01 04 A8 pp FF rd text on web page ve when camera sett g at bootup if power ty issue with the App vices for the meanting of plugging. | Auto Tilt. Comments pp: 0x00 To 0xFF normal preset s only allow 0-9, a-z, A-Z. ting on mirror or flip. on & off to preset is active. ple MAC Safari browser. Please use me. | | | |





Product: PTC310/PTC310H/PTC310U/PTC330/PTC330U PTC310N/PTC310HN/PTC310UN/PTC330N





| | NDI |
|-------------|--|
| | Camera ID AVer_NDI_Camera |
| | Group Public |
| | Set |
| | 9. Add ability to save preset for people size when turn OFF Auto Zoom. |
| | When Auto Zoom is off, camera stops zooming in/out automatically and shoots the presenter according to the shot size of the preset you choose. |
| | Preset 0 Preset 1 Preset 2 Preset 3 |
| Improvement | 9. Bug fixed: when turn off Sleep to preset and click "Timer" and then enable Sleep to preset. |
| | 10. Bug fixed: camera FOV different after call preset1. |
| | 11. Bug fixed: when power on at zone tracking mode, camera will not return to tracking point. |
| | 12. Improve Windows Camera APP compatibility. |
| | 13. Live image color improvement. (Lower down saturation a little bit) |
| Known | 9. Web GUI has known compatibility issue with the Apple MAC Safari browser. Please use |
| Issues | the Chrome browser on Apple devices for the meantime. |
| | 10. USB port does not yet support Hot plugging. |
| | When the video mode via the web is set to IP streaming only or NDI only; then when the USB |
| | port is connected to a PC, users will still see the device name on the PC but will not have any |
| | USB streaming output. |







| IP Address 61.219.195.21 Serial Number 5310895400033 MAC Address 00:18:1A:0A:E7:01 Firmware Version 0.0.0000.35 Lens Firmware Version AA35 MCU Firmware Version 4A0C8587 | Model Name | TR311HN | | |
|---|-----------------------|-------------------|------|----|
| MAC Address 00:18:1A:0A:E7:01 Firmware Version 0.0.0000.35 Lens Firmware Version AA35 MCU Firmware Version 4A0C8587 | IP Address | 61.219.195.21 | | |
| Firmware Version 0.0.0000.35 Lens Firmware Version AA35 MCU Firmware Version 4A0C8587 | Serial Number | 5310895400033 | | |
| Lens Firmware Version AA35 MCU Firmware Version 4A0C8587 | MAC Address | 00:18:1A:0A:E7:01 | | |
| MCU Firmware Version 4A0C8587 | Firmware Version | 0.0.0000.35 | | |
| Language | Lens Firmware Version | AA35 | | |
| Language Reboot | MCU Firmware Version | 4A0C8587 | | |
| Language Reboot | | | | |
| Language Reboot | | | | |
| | Language | | Rebo | ot |
| | | | | |
| | | | | |

6. Added ability to import or export of camera config file on Web UI.

| Setting | |
|----------------|----------------|
| Import Setting | Export Setting |
| | |

7. Added ability to execute some function via VISCA preset number on Web UI, allows user to execute some function from controller.

| Set VISCA Customized Fu | nctions |
|-------------------------|--|
| Function Name | Preset Numbe |
| Auto Tracking On | 168 |
| Auto Tracking Off | 169 |
| Enable Presenter mode | 164 |
| Enable Zone mode | 165 |
| Enable Hybrid mode | 166 |
| Recall Tracking Point | 162 |
| Switch Presenter | 163 |
| Switch Tracking Mode | 167 |
| Full Body | 160 |
| Upper Body | 161 |
| Tally On | 96 |
| Tally Off | 97 |
| OSD menu On/Off | 95 |
| Reboot | 200 |
| | Function Name Auto Tracking On Auto Tracking Off Enable Presenter mode Enable Zone mode Enable Hybrid mode Recall Tracking Point Switch Presenter Switch Presenter Full Body Upper Body Tally On Sub menu On/Off |

8. Added ability to use hot key to trun RTMP ON and OFF from remote control "EV+" and



| | "EV-". e.g. long press "EV+" button on remote control over1.5 sec and turn on RTMP. | | | | | | | | |
|-------------|---|--|--|--|--|--|--|--|--|
| | MEM CAMERA NELICI MEM CAMERA NELICI MEM CAMERA NELICI MEM Camera Nelici Camera Nelici Camera Nelici MEM Camera Nelici MEM Camera Nelici Mem Camera Nelici Mem Mem Mem Mem <t< th=""></t<> | | | | | | | | |
| | 9. <u>Sleep mode</u> : added ability to use UVC video OFF and camera go to a preset and this | | | | | | | | |
| | function only effective in "USB only" Video mode. | | | | | | | | |
| | 10. Sync. with tracking : added ability to use UVC video ON/ OFF to turn ON/OFF Auto | | | | | | | | |
| | Tracking and this function only effective in sleep mode. | | | | | | | | |
| | e.g. When teacher turn off ZOOM, teams or Googlemeet and Camera will automatic turn | | | | | | | | |
| | off Auto Tracking, reduce hand contract on remote control. | | | | | | | | |
| | 11. <u>Sleep Timer</u> : added ability to set a timer go to a preset after turn off UVC video. | | | | | | | | |
| | Sleep to Preset Sync. with tracking 20 Save Sleep mode can be enabled when video mode is USB only. Sleep Timer Image: Sleep Timer | | | | | | | | |
| Improvement | 14. Support NDI4.6.2 version of TR311HN.(NDI model only) | | | | | | | | |
| | 15. OBS Plug-in update. | | | | | | | | |
| | 16. The cache will be automatically reloaded when the different firmware version is detected. | | | | | | | | |
| | 17. Bug fix of "power off to preset", make camera go to correct preset. | | | | | | | | |
| Know issue | 1. When import new config file into camera and enable Sleep mode will be abnormal, need | | | | | | | | |
| | to reboot to resume normal function. | | | | | | | | |
| | 2. Web GUI has known compatibility issue with the Apple MAC Safari browser. Please | | | | | | | | |
| | use the Chrome browser on Apple devices for the meantime. | | | | | | | | |
| | 11 | | | | | | | | |



Release note

Product : Product : PTC310/PTC310H/PTC310U/PTC330U

PTC310N/PTC310HN/PTC310UN

| FW | V0.0.0000.30 |
|----------------|--|
| version | |
| Release | 2021/4/6 |
| date | |
| New | 10. Added Power Up to Preset position setting on Web UI. |
| feature | 11. Added Power Off to Preset position setting on Web UI. |
| | |
| | Power Up to Preset Power Off to Preset |
| | 0 Save 0 Save |
| | |
| | 12. Added Tracking mode SET & GET mode commands to the CGI/VISCA command list. |
| | 13. Added ability to change "Hostname" of camera on Web UI. |
| | AVer DHCP Hostname |
| | AVer AVer |
| | Live View IP Address Netmask |
| | Camera Settings 10 100 105 126 255 255 0 |
| | Gateway DNS |
| | 10.100.105.254 8.8.8.8 |
| | 品 Network |
| | 14. Relocated the Tracking Controls to the Main Menu on the Web UI. |
| | AVer |
| | O Live View |
| | Camera Settings |
| | Video & Audio |
| | Baseline |
| | Tracking Settings |
| | System Tracking Control |
| | Tracking On Off Wode Presenter |
| | Zone Camera Control Preset Pan Speed re |
| | ○ Click Track ▲ ▲ ▲ 1 16 1 → 24 |
| | ✓ ★ Zoom |
| | Zoom Speed |
| | Focus Near Limit 0.30m V High Low |
| | 15.Added Effective Tracking Area function in Presenter Mode. If this is checked, the |
| | camera can be programmed to only track the subject within a predefined area of its view. |
| er Information | |

AV





| | AV er | | | | | | | | |
|------------------|------------------|-----|---|-----------------|------|---------------|--|--|----|
| O | Live View | | | | | | | | |
| 24 | Camera Settings | ; | | | | | | | |
| | Video & Audio | | | | | | | | |
| 묢 | Network | | | | | | | | |
| ¢ | Tracking Setting | 5 | | | | | | | |
| -^- | System | | | | | | | | |
| | Tracking Control | | | | | | | | |
| Tracking Mode | On On Presenter | Off | Presenter | | Zone | • | | Hybrid | |
| | O Zone | | Tracking Sensitivity | | 2 | Tracking Poir | nt | | |
| | Hybrid | | 1 <u> </u> | | 3 | Preset | _ | Sav | 'e |
| | Click Track | | Time of Return to Tracking Point | | 3 | People Size | | | |
| | | | 3 🙆 | | 10 | | Full Body | O Upper Body | |
| | | | Effective Tracking Area | Set | | 🗹 Auto Zo | om | | |
| | | | When Effective Tracking Area is on tracks around the selected area, pl the targeted area from the live view | lease configure | | in/out auton | Zoom is off, ca natically and sl o the shot size | mera stops zoomin noots the presenter | ıg |

16. Added Auto Zoom Enable/Disable function in Presenter Mode. When checked, the initial zoom value once subject is acquired is preserved throughout the tracking experience.









| Known | 11. Web GUI has known compatibility issue with the Apple MAC Safari browser. Please use |
|--------|--|
| Issues | the Chrome browser on Apple devices for the meantime. |
| | 12. USB port does not yet support Hot plugging. |
| | When the video mode via the web is set to IP streaming only or NDI only; then when the USB |
| | port is connected to a PC, users will still see the device name on the PC, but will not have any |
| | USB streaming output. |

