









VC520 Pro Conference Camera

Quick Installation Guide

Package Contents

Camera Unit	Speakerphone Unit	Remote Controller	Power Adapter Power Cord*	
				
USB 3.0 Cable	Camera Cable (10 m)	Speakerphone Cable (10 m)	3.5 mm Audio Cable (0.9m)	L-Mount Bracket
				
Screws for Mount	Drilling Paper	Quick Guide	Warranty Card	AAA Batteries
				


*The power cord will vary depending on the standard power outlet of the country where it is sold.

More Help


For FAQs, technical support, software and user manual download, please visit:

<http://www.averusa.com>.

Overview




- | | | | |
|---|-----------------------------------|---|-------------------|
| 1 | Status LED | 5 | RS232 in/out port |
| 2 | IR sensor | 6 | Ethernet port |
| 3 | Speakerphone port
(Blue cable) | 7 | DC 12V power jack |
| 4 | USB3.1 Type B port | 8 | Kensington Lock |



- | | | | |
|----|---|----|-----------------------------|
| 9 | Speakerphone port
(For extended speakerphone
and microphone connection/
Red cable) | 11 | Line out port |
| 10 | Phone in port | 12 | Camera port
(Blue cable) |
| | | 13 | Kensington Lock |

Installation



1. Connect the camera to power outlet.



2. Connect the camera to the speakerphone using the included compatible cable.

[Note]


- Both speakerphone and camera port are marked in blue.
- The back cover of the speakerphone will need to be removed to connect the speakerphone cable.



3. Connect other necessary cables.


[Note]

- USB and RS232 cable need to secure the cable with attached screw.
- Make sure the cable is well connected to the connector on the camera before securing the cable.




4. Connect the camera to the computer.

[Note] Use the USB 3.0 cable that is included in package.



Remote Controller



*Function requires AVer PTZApp


**Not supported for VC520 Pro

- **Camera Select:** If you only have one camera and don't need to adjust custom settings, the default is camera 1. If you press camera 2 or 3 on the remote control, you will find your remote can't control your camera. In this case, please press camera 1 on your remote again.
- **SmartFrame:** Press for 1 second to switch the SmartFrame function between auto and manual
- Press and hold the number button " **1** " to turn on or off the WDR function.
- AAA Batteries (required)


Wall Mount Installation

1. Use the drilling paper included in the package to drill the holes in the wall where the user wants to mount the camera.
2. Use the screw to secure the **A** L-mount bracket on the wall.
3. Then, assemble the **A** + **B** L-mount bracket with screws (included in package).
4. After assembling the L-mount bracket, secure the lower part of L-mount bracket on the wall.
5. Pass the cables through the hole on the L-mount bracket and connect the cables to corresponding connection ports.
6. Use the screws (included in package) to secure the cameras on the L-mount bracket.


1




2




3




4



5



6



Making a Video Call

A computer is required to use this device.

Step 1: Open your video collaboration application such as Zoom, Microsoft® Teams, Skype for Business, Skype, Google Hangouts, Intel® Unite™, RingCentral, BlueJeans, V-Cube, LiveOn, CyberLink U Meeting®, TrueConf, Adobe Connect, Cisco WebEx®, Fuze, GoToMeeting™, Microsoft® Lync™, Vido, vMix, WebRTC, Wirecast, XSplit.

Step 2: Set the VC520 Pro as your primary camera device in your application (Please consult your application setup guide for details).

Step 3: Ready to make a video call.

[Note] VC520 Pro is a plug-n-play conference camera. The system requires no special drivers. For advanced setting and firmware update, please download **Aver PTZApp**.

Setup the Camera through the Web Browser

VC520 Pro has an Ethernet port for IP streaming and allows administrators to remotely control and set up the camera via an internet access. Moreover, VC520 Pro also supports RTSP and RTMP functions. For further details, please refer to user's manual or contact our technical support.


1. Make sure the VC520 Pro has an internet access connection.
2. Open the browser and enter the IP address of the camera.

[Note] The browser supports:

- Chrome: version 76.x or above
- Firefox: version 69 or above
- IE: Doesn't support

The camera default IP address is **192.168.1.168**. User can use "**Aver IP Finder**" app to find the camera (Please refer to "**Using Aver IP Finder to Find the Camera**" section).

3. When login screen is shown, enter the password (default password is **aver4321**).
4. The web main screen is displayed.



Install AVer PTZApp

In AVer PTZApp, user can configure the parameters of the camera.

Please go to <http://www.aver.com/download-center> to download the AVer PTZApp. After downloading, double-click on the file and follow the on-screen instructions to complete the installation.

Use AVer PTZApp

1. After installing the AVer PTZApp, double-click on the AVer PTZApp icon to run the application.
2. During your video call, you can use the AVer PTZApp to pan, tilt and zoom the camera in/out and enable/disable the backlight feature, set up camera Home or Sleep mode preset points. For more details, please refer to the user manual.
3. **Tracking mode:** It is a SmartFrame function which can auto detect faces of people to find the best view for all meeting participants. Users can change SmartFrame function status in AVer PTZApp. In AVer PTZApp, select **"Settings" > "Tracking mode" > "Auto frame/Manual frame/off"**.

Also, pressing  on the remote for 1 second can switch the SmartFrame function between auto and manual; a message (as figure shown) will display on the screen to indicate in auto or manual status.


[Note] While in conferencing meeting, participants must face the camera for face detection (SmartFrame).



4. **Flip:** If the camera is installed in the upside down position, please enable the **"Flip"** function in the AVer PTZApp, and the screen will display normally.




5. **Hotkey Control:** Enable hotkey control to use keyboard control camera's movement and backlight. The default is off.




A hotkey tip will display when mouse is moved to the PTZ control button in PTZ mode.

If the hotkey function is enabled after installing the PTZApp, PTZApp auto launch next time the PC reboots. Therefore, the customer can use all the hotkey commands when PTZApp is auto running in system tray.



6. **Speakerphone:** setup speakerphone function parameters.

- **Noise suppression:** Reduce ambient noise.
- **Automatically gain control:** Enable/disable the auto gain control.
- **Echo cancellation:** Enable/disable echo situation.
- **Keyboard noise suppression:** Enable/disable keyboard noise reduction.
- **Phone in jack**
 - **Phone in:** When the mobile phone is connecting to Phone in port, please select "Phone in" option.
 - **3.5 mm microphone only:** The speakerphone will transfer the sound that it receives from the external microphone (connected on phone in port) to far site.
 - **3.5 mm microphone mix in:** The speakerphone will transfer the sound that it receives from the external microphone (connected on phone in port) and speakerphone to far site.
- **Expansion mic mute**
 - **All:** To mute all connected speakerphones.
 - **Individual:** To individually mute a speakerphone and not the extended speakerphones.



Contact Information

AVer Information Inc.

668 Mission Ct.

Fremont, CA 94539

www.averusa.com

Toll-free: 1(877)528-7824

Local: 1(408)263-3828

support.usa@aver.com

Federal Communication Commission Interference Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radiofrequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning:

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

CAUTION

- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries in a safe and proper manner.